



Unique Microchip Test  
No Reagents  
Digital Readout

## Multi Parameter Test Meter

Chlorine Dioxide, Free Chlorine, Chlorite

### Kit Contents:

- ✓ ChlordioX Plus meter
- ✓ Degasser assembly including pump
- ✓ 200 ChlordioX sensors for Chlorine Dioxide or Chlorite, with calibration chip
- ✓ 100 ChloroSense sensors for Free Chlorine, including calibration chip
- ✓ Glycine Reagent (25ml)
- ✓ CR-1 Reagent (25ml)
- ✓ CR-2 Reagent (25ml)
- ✓ Sample bottle
- ✓ Stirring rods
- ✓ Hard carrying case

## ChlordioX Plus



### Multi Parameter Meter

The new ChlordioX Plus uses patented disposable sensor technology and a unique sequential method to measure Free Chlorine, Chlorine Dioxide and Chlorite across a range of applications, including food process, and drinking water.

#### The ChlordioX Plus features:

Simple operation for all levels of users. Wide operating ranges for all parameters. No interference from sample solids or color. Superior analytical performance compared to DPD or Lissamine Green methods.

Parameters:	Method:
Chlorine Dioxide	Chronoamperometry
Free Chlorine	Chronoamperometry
Chlorite	Degassing/ chronoamperometry

Analysis Time:	Range:
< 1 minute	0.02 – 50 ppm ClO <sub>2</sub>
< 1 minute	0.02 – 10 ppm Cl <sub>2</sub>
< 6 minutes	0.02 – 50 ppm ClO <sub>2</sub>

### Ordering Information

CS400	ChlordioX Plus Meter Kit for Chlorine, Chlorine Dioxide and Chlorite	\$1,820.00
CDX350	Replacement Chlorine Dioxide Sensors with Calibration Chip (pack of 500)	\$350.00
CS150	Replacement Chlorine Sensors with Calibration Chip (pack of 500)	\$310.00