

Waterproof ORP Tester

Oakton Tester Series

Item Number: **WD-35650-10**

- Waterproof, dustproof housing floats!
- Double junction electrode is ideal for dirty water, heavy metals, sulfides and organics
- Replaceable sensor lets you reuse same meter body, saving you money
- Push-button ± 150 mV offset adjustment

You'll never lose this tester by dropping it into a tank or pond; the waterproof ORPTestr floats! IP67-rated housing protects the instrument from rugged field and plant environments.

Replaceable sensor lets you reuse meter body many times without losing waterproof and dustproof protection. Push-button calibration lets standardize tester in calibration solutions, or making it agree with an established work standard. Large surface area platinum band sensor gives a faster, more stable response.



Specification

Model	WD-35650-10
Range	-999 to 1000 mV
Resolution	1 mV
Accuracy	± 150 mV
Electrode	Platinum band
Waterproof	Yes (IP67)
Power	four 1.5 V batteries